

Toyota Fortuner			
Sl.No.	Descriptions	Unit	Lungten Automobile (Inclusive of Labour Charge)
1	1st Hubs Assembly	Set	500
2	2nd Hubs Assembly	Set	500
3	3rd Hubs Assembly	Set	500
4	3rd Pinion gear	Set	500
5	4th Pinion gear	Pcs	500
6	4wd Wheel Drive Assembly	Pcs	120
7	AC Belt	Pcs	20
8	AC Fillup	Pcs	2000
9	AC Filter	Pcs	1800
10	Air Filter	Pcs	2400
11	Alternator bearing inner	Set	50
12	Alternator bearing outer	Pcs	120
13	Arm Assembly Steering idler	Pcs	250
14	Arm Bush Lower	Pcs	1250
15	Arm Bush Upper	Pcs	1250
16	Arm Steering Knuckel LH	Pcs	4500
17	Arm Steering Knuckel RH	Pcs	4500
18	Axcle Boot	Set	250
19	Axcle Cone	Pcs	2100
20	Back Light Assembly	Pcs	8500
21	Back Light Bulb Single Point	Pcs	350
22	Back Light Sensor	Pcs	120
23	Balancing Rod	Pcs	350
24	Ball Joint LWR LH	Set	3800
25	Ball Joint LWR RH	Set	3800
26	Ball Joint UPR RH/LH	Pcs	3800
27	Bar Rode Assembly Back	Pcs	2500
28	Bar Rode Assembly Front	Pcs	2500
29	Battery Amaron	Pcs	8800
30	Battery Exide	Pcs	8800
31	Battery for Key Remote	Pcs	250
32	Bearing Camshaft	Pcs	350
33	Bearing Centre Support	Pcs	1850
34	Bearing Connection Rod	Pcs	1850
35	Bearing Crankshaft	Pcs	450
36	Bearing Differential Side Gear	Pcs	1500
37	Bearing Front Wheel Inner	Pcs	8500
38	Bearing Front Wheel Outer	Pcs	20
39	Bearing Rear Axle/Wheel	Pcs	8900
40	Bearing Tail Pinion Inner	Pcs	1250

41	Bearing Tail Pinion Outer	Pcs	1250
42	Belt V for compressor & cooler	Pcs	1200
43	Body Balance Bush	Pcs	1850
44	Body balance rod	Pcs	2500
45	Body bush	Pcs	1850
46	Body Control bush	Pcs	1850
47	Body Control rod bush Lower	Pcs	1850
48	Body Control rod bush upper	Set	1850
49	Body mounting bush rear	Pcs	1850
50	Body Polish	Pcs	250
51	Boot kit drive shaft inboard joint	Set	250
52	Brake cliper pin	Set	850
53	Brake light bulb double point	Set	350
54	Brake master cylinder Assembly	Pcs	12500
55	Brake pad	Pcs	1200
56	Brake pad original	Pcs	4200
57	Brake servicing for 4 tyres	Pcs	250
58	Brake shoe	Pcs	2200
59	Bucket seat/ normal seat	Pcs	7800
60	Bumper light	Pcs	210
61	Bush front stabilizer	Pcs	1200
62	Bush front suspension LWR-RH/LH	Pcs	1250
63	Bush front suspension UPR- RH/LH	Set	1250
64	Bush spring leaf	Set	20
65	Bush spring shackle	Pcs	10
66	Camshaft Assembly	Pcs	100
67	Camshaft oil seal	Pcs	450
68	Cap. Assembly Fuel filter	Pcs	450
69	Carpet	Sq. ft.	175
70	Centre lock Assembly	Pcs	3800
71	Clutch Cable	Pcs	20
72	Clutch paddle	Set	20
73	Clutch paddle hanger	Pcs	20
74	Clutch Plate	Pcs	11500
75	Clutch release bearing	Pcs	3800
76	Clutch starter	Pcs	350
77	Coil Spring	Pcs	45
78	Coil spring bush	Pcs	25
79	Combination switch assembly	Pcs	1200
80	Connecting bearing	Pcs	1850
81	Contact point	Pcs	450
82	Coolant	Pcs	300
83	Crankchaft oil seal	Pcs	450

84	Cross bearing	Set	2800
85	Crown bearing	Set	1850
86	Cushion front shock absorber	Set	120
87	Cushion front stabilizer	Set	25
88	CV joint	Set	7800
89	CV joint bush	Pcs	180
90	Cycle pin	Pcs	50
91	Cylinder Assembly Brake Master	Pcs	14500
92	Cylinder Assembly Clutch master	Pcs	4800
93	Cylinder kit brake master	Pcs	50
94	Cylinder Kit clutch master	Pcs	120
95	Cylinder Kit front disc brake	Pcs	120
96	Cylinder Kit rear wheel	Pcs	250
97	D-Bush	Pcs	850
98	Dainama amiture	Pcs	2200
99	Dainama bearing	Pcs	1500
100	Dalla bush	Pcs	50
101	Danting	sq.ft	120
102	Dash Board Polish	Pcs	350
103	Deep Stick	Pcs	25
104	Deky lock	Pcs	13500
105	Deky pin	Pcs	450
106	Deky shocker	Pcs	2500
107	Delivery Valve	Set	450
108	Diesel/Fuel Filter	Set	2775
109	Differential oil seal	Set	1200
110	Disc Cutting	Set	850
111	Door glass regulator motor	Pcs	10
112	Door head lamp LH	Nos	120
113	Door head lamp RH	Nos	120
114	Door pad	Pcs	450
115	Dot 3 original	Set	550
116	Drive shaft assembly	Ltr	21000
117	Drive Shaft Boot (Inner)	Set	1650
118	Drive Shaft Boot (Outer)	Set	1650
119	Drive shaft oil seal	Pcs	850
120	EGR assembly (Exhaust Pipe)	Pcs	120
121	End sub Assembly tie rod LH	Set	25
122	End sub Assembly tie rod RH	Pcs	25
123	Engine Block	Pcs	0
124	Engine Oil	Pcs	450
125	Engine Oil Rimula-x	Pcs	450
126	Fan belt	Pcs	2800

127	Fan sub Assembly	Pcs	550
128	Fender	Pcs	4500
129	Flashing oil	Pcs	300
130	Floor mat	Pcs	650
131	Flooring	Pcs	500
132	Fly wheel Assembly	Ltr	120
133	Fog light	Pcs	450
134	Foot Mat	Charges	1000
135	Foot raise	Sqft	50
136	Front brake booster Assembly	Pcs	6500
137	Front Bumper	Pcs	14500
138	Front Bumper	Pcs	0
139	Front door glass LH/RH	Pcs	6500
140	Front wheel check nut	Pcs	250
141	Front wheel cross bearing	Pcs	120
142	Fuel meter	Pcs	120
143	Gasket engine overhaul	Pcs	5500
144	Gasket power steering control	Set	500
145	Gear box coupling	Pcs	350
146	Gear box maintainence	Set	1200
147	Gear box mounting	Pcs	1800
148	Gear box Oil seal	Pcs	1200
149	Gear lever bush	Set	45
150	Gear Lever Knob	Pcs	150
151	Gear oil	Pcs	300
152	Glow plug	Pcs	2800
153	Glow timer	Pcs	120
154	Grass Mat	Set	3300
155	Grease	Pcs	300
156	Greasing for chases	Pcs	120
157	Grill Radiator back	Pcs	2500
158	Grill Radiator chrom plate	Pcs	2500
159	Hand brake cable Back	Set	65
160	Hand brake cable Front	Ltr	1200
161	Hand brake cable rear	Pcs	6500
162	Hand brake shoe	Pcs	2200
163	Hand pump Assembly	Pcs	1800
164	Head gasket	Pcs	3500
165	Head Lamp Assembly	Pcs	4800
166	Head Rotor	Pcs	250
167	Heater repair	Pcs	250
168	Heating timer	Pcs	250
169	Horn Set	Pcs	950

170	Hose pipe	Pcs	650
171	Hose pipe clam	Pcs	120
172	Hub Greasing for both side	Pcs	25
173	Idle Arm	Charges	25
174	Ignation Assembly	Pcs	35
175	Indicator Flasher (Hazard Light)	Pcs	140
176	Indicator relay	Pcs	140
177	Indicator/side light bulb	Pcs	45
178	Injector Nozzle	Pcs	1280
179	Interior and exterior car wash	Pcs	2500
180	Jack	Pcs	3800
181	Jack Lever	Pcs	850
182	Jug lever	Set	850
183	Kerosene oil	Pcs	120
184	King pin bearing	Pcs	20
185	Km senser	Pcs	20
186	Latheral bush	Pcs	120
187	Latheral rod	Pcs	850
188	LED back light	Pcs	5000
189	LED Head light	Pcs	7500
190	Lens front indicator LH	Pcs	25
191	Lens front indicator RH	Pcs	25
192	Lens RR combination LH	Pcs	25
193	Lens RR combination RG	Pcs	25
194	Letheral arm bush big	Pcs	450
195	Letheral arm bush small	Pcs	450
196	Linner	Pcs	120
197	Lock free wheelhub	Pcs	120
198	Main bearing	Set	1450
199	Mechanic hire charge	Pcs	250
200	Metal bush	Pcs	1200
201	Mirror LH	Set	4500
202	Mirror rear view	Pcs	120
203	Mirror RH	Ltr	4500
204	Mobile Filter	Set	1350
205	Mud guard	Pcs	2500
206	Music system	Pcs	20
207	Nipple greasing	Set	480
208	Number plate	Pcs	450
209	O ring	Pcs	25
210	Oil Filter	Pcs	1350
211	Oil pump assembly	Set	480
212	Oil Pump Gear	Pcs	480

213	Oil seal camshaft	Set	650
214	Oil seal engine gear	Pcs	650
215	Oil seal front axle inner	Pcs	650
216	Oil seal front hub outer	Pcs	650
217	Oil seal rear axle inner	Pcs	1200
218	Oil seal rear axle outer	Pcs	1200
219	Oil seal tail pinion	Pcs	250
220	Oil seal timing gear case	Pcs	120
221	Out put gear assembly	Pcs	120
222	Painting	sq.ft	500
223	Pinion	mtr	20
224	Piston	Pcs	1200
225	Piston Ring	Set	3500
226	Pitman Arm	Pcs	50
227	Pitman Arm with Power Steering	Pcs	50
228	Popular sharf assembly Front	Pcs	4800
229	Popular sharf spider kid	Set	3500
230	Power steering belt	Pcs	1200
231	Power steering kit	Pcs	1200
232	Power steering motor	Pcs	1900
233	Power steering oil	Pcs	550
234	Power window switch	Set	3800
235	Pressure plate	Set	11500
236	Propeler shaft rear	Pcs	120
237	Pump service kit	Pcs	120
238	Pump switch	Set	20
239	Push lock	Pcs	20
240	Rack end	Set	25
241	Radiator Cap	Pcs	550
242	Radiator heater assembly	Pcs	8500
243	Raidator Cap	Pcs	550
244	Rain Guard	Pcs	1200
245	Rare bumper	Pcs	1200
246	Rare Spring Spacer	Set	120
247	Rear balance spring	Pcs	120
248	Rear balance spring rod	Set	50
249	Rear cabin glass (Laminated)	Pcs	50
250	Rear Dekey Glass	Pcs	120
251	Rear door glass LH/RH	Pcs	20
252	Regulator MC for windows	Pcs	120
253	Relay starter	Pcs	120
254	Release bearing	Set	3800
255	Roller bearing	Pcs	20

256	Rope	Pcs	550
257	Seat Ball stud for steering drag	Pcs	20
258	Seat Cover	Pcs	7500
259	Self Armature	Set	1200
260	Self Bendix	Pcs	4500
261	Self planger	Pcs	1500
262	Self starter assembly	Pcs	120
263	Sensor Scanner	Pcs	120
264	Shifting lever	Pcs	120
265	Shock absorber bush each	Pcs	120
266	Shock absorber front each	Pcs	5800
267	Shock absorber rear each	Pcs	5500
268	Side bearing	Pcs	450
269	Side light assembly	Pcs	650
270	Spare key	Pcs	1200
271	Spare tyre cover	Pcs	120
272	Spider cable assemble with sensor	Pcs	100
273	Spider kit universal joint (Cross bearing)	Set	120
274	Spiral cable assembly	Charge	8500
275	Spring rear leaf 2nd	Pcs	0
276	Spring rear leaf 3rd	Set	0
277	spring rear leaf 4th	Pcs	0
278	Spring rear leaf 5th	Set	0
279	Spring rear leaf main	Pcs	0
280	stabilizer link rod end	Pcs	2800
281	Stabilizer rod assembly	Set	750
282	Steering Box Assembly	Pcs	20
283	Steering column	Set	120
284	Steering Cover	Pcs	1100
285	Steering cross rod	Set	650
286	Steering Damper	Pcs	20
287	Steering knuckle Kit	Pcs	120
288	Steering rack assembly	Set	35000
289	Steering rack boot	Set	1800
290	Steering rack end	Nos	3800
291	Steering Yoke	Nos	250
292	Sterring column bush	Nos	250
293	Sun Visor Assembly	Nos	1100
294	Switch fuel level warning	Nos	500
295	Thermostat valve	Nos	1750
296	Thrust washer	Nos	1500
297	Tie rod end	Nos	2800
298	Timing Belt	Nos	3000

299	Timing Chain	Nos	0
300	Timing tension bearing	Nos	1200
301	Top shaft bearing	Nos	1200
302	Tubeless nozzle	Nos	250
303	Tyre Tube	Nos	1150
304	Valve	Nos	120
305	Valve cap	Nos	120
306	Valve guide	Nos	250
307	Valve lifter sim	Nos	120
308	Valve sheet	Nos	250
309	Voltage Regulator	Nos	250
310	Water pump Assembly	Nos	6500
311	Water servicing/Air servicing	Nos	550
312	Wheel alignment	Nos	650
313	Wheel bearing with hubs assembly	Nos	8500
314	Wheel bolt front/rear	Nos	250
315	Wheel cover	Set	1200
316	Wheel cylinder	Nos	2500
317	Wheel drum	Nos	9500
318	Wheel drum cover	Nos	200
319	Wheel nuts	Nos	250
320	Window curtain Set	Nos	4500
321	Windshield bid	Nos	550
322	Windshield glass	Nos	17500
323	Windshield gum	Nos	600
324	Wiper arm	Nos	500
325	Wiper blade	Nos	350
326	Wiper Tank	Nos	650