

**Toyota Coaster Bus**

<u>Sl.No.</u>	Description	Unit	Lungten Automobile (Inclusive of Labour Charge)
1	1st Hubs Assembly	Set	500
2	2nd Hubs Assembly	Set	500
3	3rd Hubs Assembly	Set	500
4	3rd Pinion gear	Set	500
5	4th Pinion gear	Pcs	500
6	4wd Wheel Drive Assembly	Pcs	25
7	AC Belt	Pcs	1250
8	AC Fillup	Pcs	2000
9	AC Filter	Pcs	175
10	Air Filter	Pcs	2500
11	Alternator bearing inner	Set	50
12	Alternator bearing outer	Pcs	120
13	Arm Assembly Steering idler	Pcs	250
14	Arm Bush Lower	Pcs	1850
15	Arm Bush Upper	Pcs	1850
16	Arm Steering Knuckel LH	Pcs	25
17	Arm Steering Knuckel RH	Pcs	25
18	Axcle Boot	Set	25
19	Axcle Cone	Pcs	1200
20	Back Light Assembly	Pcs	7500
21	Back Light Bulb Single Point	Pcs	350
22	Back Light Sensor	Pcs	120
23	Balancing Rod	Pcs	350
24	Ball Joint LWR LH	Set	2500
25	Ball Joint LWR RH	Set	2500
26	Ball Joint UPR RH/LH	Pcs	2500
27	Bar Rode Assembly Back	Pcs	225
28	Bar Rode Assembly Front	Pcs	225
29	Battery Amaron	Pcs	11800
30	Battery Exide	Pcs	11800
31	Battery for Key Remote	Pcs	250
32	Bearing Camshaft	Pcs	350
33	Bearing Centre Support	Pcs	1850
34	Bearing Connection Rod	Pcs	1850
35	Bearing Crankshaft	Pcs	450
36	Bearing Differential Side Gear	Pcs	1500
37	Bearing Front Wheel Inner	Pcs	1450
38	Bearing Front Wheel Outer	Pcs	1850
39	Bearing Rear Axle/Wheel	Pcs	1800

40	Bearing Tail Pinion Inner	Pcs	1250
41	Bearing Tail Pinion Outer	Pcs	1250
42	Belt V for compressor & cooler	Pcs	25
43	Body Balance Bush	Pcs	50
44	Body balance rod	Pcs	25
45	Body bush	Pcs	650
46	Body Control bush	Pcs	50
47	Body Control rod bush Lower	Pcs	25
48	Body Control rod bush upper	Set	25
49	Body mounting bush rear	Pcs	450
50	Body Polish	Pcs	250
51	Boot kit drive shaft inboard joint	Set	250
52	Brake cliper pin	Set	850
53	Brake light bulb double point	Set	45
54	Brake master cylinder Assembly	Pcs	8500
55	Brake pad	Pcs	1800
56	Brake pad original	Pcs	3450
57	Brake servicing for 4 tyres	Pcs	250
58	Brake shoe	Pcs	1800
59	Bucket seat/ normal seat	Pcs	25
60	Bumper light	Pcs	25
61	Bush front stabilizer	Pcs	1500
62	Bush front suspension LWR- RH/LH	Pcs	1200
63	Bush front suspension UPR- RH/LH	Set	1200
64	Bush spring leaf	Set	650
65	Bush spring shackle	Pcs	650
66	Camshaft Assembly	Pcs	180
67	Camshaft oil seal	Pcs	450
68	Cap. Assembly Fuel filter	Pcs	450
69	Carpet	Sq. ft.	175
70	Centre lock Assembly	Pcs	120
71	Clutch Cable	Pcs	500
72	Clutch paddle	Set	25
73	Clutch paddle hanger	Pcs	20
74	Clutch Plate	Pcs	12800
75	Clutch release bearing	Pcs	5800
76	Clutch starter	Pcs	45
77	Coil Spring	Pcs	25
78	Coil spring bush	Pcs	50
79	Combination switch assembly	Pcs	350

80	Connecting bearing	Pcs	450
81	Contact point	Pcs	450
82	Coolant	Pcs	300
83	Crankchaft oil seal	Pcs	1500
84	Cross bearing	Set	3800
85	Crown bearing	Set	120
86	Cushion front shock absorber	Set	25
87	Cushion front stabilizer	Set	20
88	CV joint	Set	250
89	CV joint bush	Pcs	50
90	Cycle pin	Pcs	45
91	Cylinder Assembly Brake Master	Pcs	14500
92	Cylinder Assembly Clutch master	Pcs	4800
93	Cylinder kit brake master	Pcs	120
94	Cylinder Kit clutch master	Pcs	120
95	Cylinder Kit front disc brake	Pcs	250
96	Cylinder Kit rear wheel	Pcs	2800
97	D-Bush	Pcs	850
98	Dainama amiture	Pcs	500
99	Dainama bearing	Pcs	450
100	Dalla bush	Pcs	120
101	Danting	Sq.ft	120
102	Dash Board Polish	Pcs	350
103	Deep Stick	Pcs	120
104	Deky lock	Pcs	1500
105	Deky pin	Pcs	150
106	Deky shocker	Pcs	50
107	Delivery Valve	Set	500
108	Diesel/Fuel Filter	Set	1800
109	Differential oil seal	Set	850
110	Disc Cutting	Set	980
111	Door glass regulator motor	Pcs	120
112	Door head lamp LH	Nos	120
113	Door head lamp RH	Nos	120
114	Door pad	Pcs	550
115	Dot 3 original	Set	550
116	Drive shaft assembly	Ltr	25
117	Drive Shaft Boot (Inner)	Set	1650
118	Drive Shaft Boot (Outer)	Set	1650
119	Drive shaft oil seal	Pcs	850
120	EGR assembly (Exhaust Pipe)	Pcs	120

121	End sub Assembly tie rod LH	Set	25
122	End sub Assembly tie rod RH	Pcs	25
123	Engine Block	Pcs	450
124	Engine Oil	Pcs	450
125	Engine Oil Rimula-x	Pcs	450
126	Fan belt	Pcs	1800
127	Fan sub Assembly	Pcs	120
128	Fender	Pcs	120
129	Flashing oil	Pcs	300
130	Floor mat	Pcs	850
131	Flooring	Pcs	1200
132	Fly wheel Assembly	Ltr	450
133	Fog light	Pcs	100
134	Foot Mat	Charges	50
135	Foot raise	Sqft	2500
136	Front brake booster Assembly	Pcs	4500
137	Front Bumper	Pcs	7500
138	Front Bumper	Pcs	0
139	Front door glass LH/RH	Pcs	250
140	Front wheel check nut	Pcs	250
141	Front wheel cross bearing	Pcs	2800
142	Fuel meter	Pcs	250
143	Gasket engine overhaul	Pcs	4500
144	Gasket power steering control	Set	20
145	Gear box coupling	Pcs	1200
146	Gear box maintainence	Set	100
147	Gear box mounting	Pcs	45
148	Gear box Oil seal	Pcs	1850
149	Gear lever bush	Set	150
150	Gear Lever Knob	Pcs	300
151	Gear oil	Pcs	350
152	Glow plug	Pcs	2800
153	Glow timer	Pcs	120
154	Grass Mat	Set	175
155	Grease	Pcs	300
156	Greasing for chases	Pcs	300
157	Grill Radiator back	Pcs	6800
158	Grill Radiator chrom plate	Pcs	65
159	Hand brake cable Back	Set	20
160	Hand brake cable Front	Ltr	1800
161	Hand brake cable rear	Pcs	4500

162	Hand brake shoe	Pcs	25
163	Hand pump Assembly	Pcs	3500
164	Head gasket	Pcs	3000
165	Head Lamp Assembly	Pcs	1850
166	Head Rotor	Pcs	250
167	Heater repair	Pcs	250
168	Heating timer	Pcs	45
169	Horn Set	Pcs	45
170	Hose pipe	Pcs	650
171	Hose pipe clam	Pcs	850
172	Hub Greasing for both side	Pcs	120
173	Idle Arm	Charges	35
174	Ignation Assembly	Pcs	20
175	Indicator Flasher (Hazard Light)	Pcs	140
176	Indicator relay	Pcs	45
177	Indicator/side light bulb	Pcs	45
178	Injector Nozzle	Pcs	150
179	Interior and exterior car wash	Pcs	45
180	Jack	Pcs	4800
181	Jack Lever	Pcs	850
182	Jug lever	Set	850
183	Kerosene oil	Pcs	120
184	King pin bearing	Pcs	20
185	Km senser	Pcs	20
186	Latheral bush	Pcs	20
187	Latheral rod	Pcs	20
188	LED back light	Pcs	120
189	LED Head light	Pcs	120
190	Lens front indicator LH	Pcs	25
191	Lens front indicator RH	Pcs	25
192	Lens RR combination LH	Pcs	25
193	Lens RR combination RG	Pcs	25
194	Letheral arm bush big	Pcs	45
195	Letheral arm bush small	Pcs	35
196	Linner	Pcs	120
197	Lock free wheelhub	Pcs	120
198	Main bearing	Set	250
199	Mechanic hire charge	Pcs	250
200	Metal bush	Pcs	1500
201	Mirror LH	Set	1500
202	Mirror rear view	Pcs	1200

203	Mirror RH	Ltr	1500
204	Mobile Filter	Set	1350
205	Mud guard	Pcs	1200
206	Music system	Pcs	4500
207	Nipple greasing	Set	980
208	Number plate	Pcs	450
209	O ring	Pcs	25
210	Oil Filter	Pcs	1350
211	Oil pump assembly	Set	25
212	Oil Pump Gear	Pcs	550
213	Oil seal camshaft	Set	650
214	Oil seal engine gear	Pcs	650
215	Oil seal front axle inner	Pcs	650
216	Oil seal front hub outer	Pcs	580
217	Oil seal rear axle inner	Pcs	540
218	Oil seal rear axle outer	Pcs	650
219	Oil seal tail pinion	Pcs	850
220	Oil seal timing gear case	Pcs	1200
221	Out put gear assembly	Pcs	500
222	Painting	Sq.ft	20
223	Pinion	mtr	120
224	Piston	Pcs	120
225	Piston Ring	Set	2500
226	Pitman Arm	Pcs	25
227	Pitman Arm with Power Steering	Pcs	25
228	Popular sharf assembly Front	Pcs	120
229	Popular sharf spider kid	Set	160
230	Power steering belt	Pcs	1800
231	Power steering kit	Pcs	140
232	Power steering motor	Pcs	850
233	Power steering oil	Pcs	550
234	Power window switch	Set	2500
235	Pressure plate	Set	15000
236	Propeler shaft rear	Pcs	25
237	Pump service kit	Pcs	1250
238	Pump switch	Set	20
239	Push lock	Pcs	125
240	Rack end	Set	125
241	Radiator Cap	Pcs	550
242	Radiator heater assembly	Pcs	250
243	Raidator Cap	Pcs	550

244	Rain Guard	Pcs	1200
245	Rare bumper	Pcs	550
246	Rare Spring Spacer	Set	250
247	Rear balance spring	Pcs	50
248	Rear balance spring rod	Set	250
249	Rear cabin glass (Laminated)	Pcs	25
250	Rear Dekey Glass	Pcs	0
251	Rear door glass LH/RH	Pcs	120
252	Regulator MC for windows	Pcs	1200
253	Relay starter	Pcs	1200
254	Release bearing	Set	6800
255	Roller bearing	Pcs	35
256	Rope	Pcs	250
257	Seat Ball stud for steering drag	Pcs	250
258	Seat Cover	Pcs	0
259	Self Armature	Set	10
260	Self Bendix	Pcs	6800
261	Self planger	Pcs	1850
262	Self starter assembly	Pcs	0
263	Sensor Scanner	Pcs	1850
264	Shifting lever	Pcs	120
265	Shock absorber bush each	Pcs	250
266	Shock absorber front each	Pcs	3800
267	Shock absorber rear each	Pcs	3800
268	Side bearing	Pcs	250
269	Side light assembly	Pcs	250
270	Spare key	Pcs	450
271	Spare tyre cover	Pcs	1450
272	Spider cable assemble with sensor	Pcs	250
273	Spider kit universal joint (Cross bearing)	Set	120
274	Spiral cable assembly	Charge	100
275	Spring rear leaf 2nd	Pcs	2800
276	Spring rear leaf 3rd	Set	1500
277	spring rear leaf 4th	Pcs	1200
278	Spring rear leaf 5th	Set	1500
279	Spring rear leaf main	Pcs	2800
280	stabilizer link rod end	Pcs	1100
281	Stabilizer rod assembly	Set	25
282	Steering Box Assembly	Pcs	3800
283	Steering column	Set	45
284	Steering Cover	Pcs	1100

285	Steering cross rod	Set	60
286	Steering Damper	Pcs	80
287	Steering knuckle Kit	Pcs	65
288	Steering rack assembly	Set	20
289	Steering rack boot	Set	120
290	Steering rack end	Nos	120
291	Steering Yoke	Nos	1200
292	Sterring column bush	Nos	3800
293	Sun Visor Assembly	Nos	250
294	Switch fuel level warning	Nos	250
295	Thermostat valve	Nos	1100
296	Thrust washer	Nos	500
297	Tie rod end	Nos	2800
298	Timing Belt	Nos	3800
299	Timing Chain	Nos	25
300	Timing tension bearing	Nos	1200
301	Top shaft bearing	Nos	450
302	Tubeless nozzel	Nos	350
303	Tyre Tube	Nos	1200
304	Valve	Nos	250
305	Valve cap	Nos	350
306	Valve guide	Nos	250
307	Valve lifter sim	Nos	350
308	Valve sheet	Nos	250
309	Voltage Regulator	Nos	120
310	Water pump Assembly	Nos	11000
311	Water servicing/Air servicing	Nos	1200
312	Wheel alignment	Nos	850
313	Wheel bearing with bubs assembly	Nos	1850
314	Wheel bolt front/rear	Nos	350
315	Wheel cover	Set	550
316	Wheel cylinder	Nos	2800
317	Wheel drum	Nos	1650
318	Wheel drum cover	Nos	250
319	Wheel nuts	Nos	200
320	Window curtain Set	Nos	2500
321	Windshield bid	Nos	1200
322	Windshield glass	Nos	0
323	Windshield gum	Nos	600
324	Wiper arm	Nos	1200
325	Wiper blade	Nos	350

326	Wiper Tank	Nos	600
-----	------------	-----	-----